

BTX1 PRO S

Bluetooth

POCKET GUIDE




Frequency: 2.4GHz
Max power: 100mW

ENGLISH

MIDLAND


ON/OFF

POWER ON



- Blue led flashing
- Sound alert
- Operating mode status

POWER OFF




- Red led flashing
- Sound alert

PAIRING PROCEDURES

ALL PAIRINGS

Main pairing (music, voice)
ex: phone-TFT-GPS


Secondary pairing (voice)
ex: GPS, 2nd phone



Pairing to:
Midland unit
Different brand unit



Pairing to:
Midland unit
(passenger)




Pairing to:
Midland unit
CONFERENCE

MUSIC SHARE VOX

PROCEDURES


To enter Setup mode

Status: Power off



- Steady red led

To exit Setup/interrupt the pairing



To reset the pairing


Status: Setup mode




- Blue led lights up and then switches to steady red

PAIRING TO A MIDLAND UNIT

Status: both units must be in Setup mode



- Red/blue led blinks
- Blue light on 1 sec




Pairing successful

- Then steady red light


Note: to pair another Midland unit, follow the same procedure but press buttons 1 or 3.

PAIRING TO A DIFFERENT BRAND UNIT

Status: Midland unit is in Setup mode



- Red/blue led blinks from fast to slow, keep pressed until the led blinks slowly




From the other brand unit, start the "phone" pairing procedure.

When both units stop flashing, Pairing successful!




PAIRING TO A PHONE/GPS

Status: Setup mode



- Red/blue led blinks



Searching Bluetooth device on your smartphone/GPS. If required enter PIN code (0000).

- Blue led on 1 sec

Pairing successful

Note: to pair a second phone/GPS (in mono audio only!), follow the same procedure but press Vol- button.

FUNCTIONS

OPERATIVE MODES

Intercom mode: talk to another unit.


Phone mode: calls or manage music.

FM radio mode: Listen, seek, store FM radio stations.


To change Operative mode

Status: Power on

To toggle from one mode to another one



- Voice announcement



INTERCOM MODE

To open/close intercom communication

Status: Intercom mode




- Beep sound

Note: if you have another unit paired, press buttons 1 or 3 to open/close intercom.


To open Intercom using voice

Status: in all modes



To enable/disable Vox

Status: in all modes



- "Vox enable/disable"


To open Universal Intercom

Status: Intercom mode



- Beep sound

To close Universal Intercom



Note: To open/close audio from different brand unit use the voice dial command (some models need to send the command twice).

To enable/disable Conference


Status: all modes



Note: The devices paired Vol+/- are temporary disconnected.

To open/close Conference communication

Open/close to single unit




Open to all

PHONE MODE

To make a phone call

Status: Phone mode



"Siri" (iPhone)
"Google assistant" (Android)

To answer an incoming call



- To close a call

- To reject a call

Note: if you have a 2nd phone paired on VOL- button, use Button 3


Listen to music

Status: Phone mode




Select the app to play music.

To share music with the second unit




- "Music share on"
- Beep sound (confirmation)

To stop music share



FM RADIO MODE

Status: FM radio mode



Play/Pause

Seek up



Memory up


Memory down

Note: to save an FM Radio station use our application, our software or follow the procedure written in the user manual.

SHORTCUTS

To play/pause music

Status: Intercom mode/FM radio mode




To open Intercom while listening to music and music share

Status: Phone mode



Operative modes status reminder



- Voice announcement

FOR MORE INFO VISIT:

www.midlandeurope.com

- Watch tutorial video
- Download software
- Download application
- Read complete manual instruction